

§ 38.15–20

devices, shall be installed in these spaces. Electric motors shall be segregated from these spaces by a gastight bulkhead. Electric lighting of the explosion-proof type may be installed in these spaces provided all switching is done from outside the space.

(c) All cargo tanks, piping, valves, etc., shall be effectively grounded to the vessel's hull. Tanks with an insulated inner shell (primary barrier) shall have an effective grounding bond to the outer shell (secondary barrier) or to the vessel's hull.

(d) Electric submerged motor cargo pumps may be used, when in compliance with the following requirements and subject to approval by the Commandant.

(1) Design details of the submerged motor pump, with an evaluation of the cooling efficiency of the product being pumped, shall be submitted.

(2) Provisions shall be made to exclude air from the tanks containing cargo in either vapor or liquid phase. The pump motor shall be deenergized when this condition is not satisfied.

(3) A liquid level sensing device shall automatically shut down the motor and sound an alarm at a predetermined low liquid level. The alarm location may be the station from which cargo handling is controlled or such other location outside the cargo area as is acceptable to the Commandant.

(4) Details of the power cable, tank penetrations and pump connections shall be submitted.

(5) An auxiliary means of emptying the cargo tanks shall be provided in accordance with § 38.10–10(d).

(6) Means for positively disconnecting the power supply between the switchboard and the pump power panel shall be provided, i.e., disconnect links, lockable breakers, etc.

(7) All materials used in the fabrication of the submerged motor cargo pumps shall be suitable for use with the liquid cargo at the design pressures and temperatures.

§ 38.15–20 Remote shutdowns—TB/ALL.

(a) All machinery associated with cargo loading, unloading, or cooling shall be capable of being shut down from a remote location. This location

46 CFR Ch. I (10–1–08 Edition)

may be the station from which the cargo handling is controlled or such other location outside the cargo area as is acceptable to the Commandant.

(b) [Reserved]

Subpart 38.20—Venting and Ventilation

§ 38.20–1 Venting—T/ALL.

(a) Each safety relief valve installed on a cargo tank shall be connected to a branch vent of a venting system which shall be constructed so that the discharge of gas will be directed vertically upward to a point which shall extend to a height above the weather deck equal to at least one-third the beam of the vessel and to a minimum of at least 10 feet, and shall terminate at a comparable distance from any other living or working space, ventilator inlet, or source of vapor ignition. When special conditions will prevent the vent line header outlets being permanently installed at a height above the deck of one-third the beam of the vessel, then an adjustable system shall be provided which, when extended vertically, shall be capable of reaching a height of one-third the beam of the vessel.

(b) The capacity of branch vents or vent headers shall depend upon the number of cargo tanks connected to such branch or header as provided for in the Table 38.20–1(b), and upon the total safety relief valve discharge capacity.

TABLE 38.20–1(b)—CAPACITY OF BRANCH VENTS OR VENT HEADERS

Number of cargo tanks	Percent of total valve discharge
1 or 2	100
3	90
4	80
5	70
6 or more	60

(c) In addition to the requirements specified in paragraphs (a) and (b) of this section, the size of the branch vents or vent headers, shall be such that the back pressure in the relief valve discharge lines shall not be more than 10 percent of the safety relief valve setting. In nonpressure vessel vent systems, however, where the maximum back pressure of 10 percent of